

1 Before driving

- 1-1. **Hybrid system**
 - Hybrid system..... 34
- 1-2. **Key information**
 - Keys 47
- 1-3. **Opening, closing and locking the doors and trunk**
 - Smart access system with push-button start 52
 - Wireless remote control..... 65
 - Doors..... 68
 - Trunk..... 73
- 1-4. **Adjustable components (seats, mirrors, steering wheel)**
 - Front seats..... 80
 - Power rear seat..... 86
 - Driving position memory 96
 - Rear seat position memory 102
 - Head restraints..... 104
 - Seat belts 107
 - Steering wheel..... 114
 - Anti-glare inside rear view mirror 115
 - Outside rear view mirrors..... 117
- 1-5. **Opening and closing the windows and moon roof**
 - Power windows..... 119
 - Moon roof 122
- 1-6. **Refueling**
 - Opening the fuel tank cap..... 126
- 1-7. **Theft deterrent system**
 - Immobilizer system 131
 - Alarm..... 133
- 1-8. **Safety information**
 - Correct driving posture 136
 - SRS airbags 138
 - Front passenger occupant classification system..... 152
 - Child restraint systems 157
 - Installing child restraints..... 162

2 When driving

2-1. Driving procedures

Driving the vehicle.....	174
Power (ignition) switch.....	183
EV drive mode.....	187
Transmission.....	189
Turn signal lever.....	193
Parking brake.....	194
Brake Hold.....	196
Horn.....	198

2-2. Instrument cluster

Gauges and meters.....	199
Indicators and warning lights.....	204
Multi-information display.....	208

2-3. Operating the lights and windshield wipers

Headlight switch.....	212
Automatic High Beam.....	215
Fog light switch.....	220
Windshield wipers and washer.....	221
Headlight cleaner switch.....	224

2-4. Using other driving systems

Cruise control.....	225
Dynamic radar cruise control.....	228
Intuitive parking assist.....	240
LKA (Lane-Keeping Assist).....	248
Electronically modulated air suspension.....	255
Advanced parking guidance system.....	257
Driving assist systems.....	298
Pre-Collision System.....	305

2-5. Driving information

Cargo and luggage.....	315
Vehicle load limits.....	318
Winter driving tips.....	320
Trailer towing.....	324
Dinghy towing.....	325

3 Interior features

3-1. Using the touch screen

Touch screen	328
Set up screen	329
Information screen	330

3-2. Using the air conditioning system and defogger

Front air conditioning system	331
Rear air conditioning system	344
Rear window and outside rear view mirror defoggers	352
Windshield wiper de-icer	353

3-3. Using the interior lights

Interior lights list	354
• Interior lights	355
• Personal lights	356

3-4. Using the storage features

List of storage features	358
• Glove box	360
• Coin holder	361
• Door pockets	361
• Cup holders	362
• Console box	363
• Non smokers boxes	365
• Auxiliary boxes	366

3-5. Other interior features

Sun visors	369
Vanity mirrors	370
Outside temperature display	371
Ashtrays	372
Cigarette lighters	373
Power outlets	375
Heated steering wheel	378
Climate control seats/seat heaters	380
Armrest (5-seat models)	384
Retractable table (4-seat models)	385
Rear sunshade	387
Rear door sunshades	390
Coat hooks	393
Floor mat	394
Trunk features	395
Garage door opener	397
Safety Connect	403

4 Maintenance and care

4-1. Maintenance and care

Cleaning and protecting the vehicle exterior	412
Cleaning and protecting the vehicle interior	415

4-2. Maintenance

Maintenance requirements	418
General maintenance	420
Emission inspection and maintenance (I/M) programs	423

4-3. Do-it-yourself maintenance

Do-it-yourself service precautions	424
Hood	427
Positioning a floor jack	428
Engine compartment	430
12-volt battery	442
Tires	446
Tire inflation pressure	455
Wheels	459
Air conditioning filter	461
Electronic key battery	464
Checking and replacing fuses	466
Headlight aim	472
Light bulbs	475

5 When trouble arises

5-1. Essential information

Emergency flashers	488
If your vehicle needs to be towed	489
If you think something is wrong	495
Event data recorder	496

5-2. Steps to take in an emergency

If a warning light turns on or a warning buzzer sounds... ..	498
If a warning message is displayed	507
If you have a flat tire	510
If the hybrid system will not start	518
If the shift lever cannot be shifted from "P"	520
If the parking brake cannot be released	521
If the electronic key does not operate properly	523
If the 12-volt battery is discharged	526
If your vehicle overheats	529
If the vehicle becomes stuck	533
If your vehicle has to be stopped in an emergency	534

6

Vehicle specifications

6-1. Specifications

Maintenance data
 (fuel, oil level, etc.)..... 536

Fuel information..... 549

Tire information..... 552

6-2. Customization

Customizable features..... 563

7

For owners

Reporting safety defects
 for U.S. owners..... 574

Seat belt instructions
 for Canadian owners
 (in French)..... 575

Index

Abbreviation list..... 578

Alphabetical index 580

What to do if... 592

1

2

3

4

5

6

7